

*FOR PIER SPACING REFER TO SET UP MANUAL

MARRIAGE WALL PIER

WATER INLET

DRAIN

ELECTRICAL DROP

DOOR PIER

DP

DP

REGULAR PIER