



*THIS FOOTER DIAGRAM IS FOR STANDARD PRODUCT ONLY
 *FOR PIER SPACING REFER TO SET UP MANUAL

- MW** MARRIAGE WALL PIER
- W** WATER INLET
- D** DRAIN
- E** ELECTRICAL DROP
- DP** DOOR PIER
- DP** DOOR PIER
- REGULAR PIER**